

DMX Channel--Classic Par 18*15w RGBWA-UV 6 IN 1, 10chs

Channel	Channel Function	Directions
CH1	Dimmer	R,G,B,W,A,UVdimmer, linear dimmer, from dark to bright
CH2	Strobe	R,G,B,W,A,UV strobe, from slow to fast
CH3	Function Selection	0-50, DMX 8 channel control, 51-100 saltus step, 101-150 gradual change, 151-200 pulse, 201-255: sound active
CH4	Function Speed	Function speed from slow to fast
CH5	Red Dimmer	Red dimmer, linear dimmer, from dark to bright
CH6	Green Dimmer	Green dimmer, linear dimmer, from dark to bright
CH7	Blue Dimmer	Blue dimmer, linear dimmer, from dark to bright
CH8	White Dimmer	White dimmer, linear dimmer, from dark to bright
CH9	Amber dimmer	Amber Dimmer, Linear dimmer, from dark to bright
CH10	Purple dimmer	Purple dimmer Linear dimmer, from dark to bright